

## **Product Technical Data Sheet**

# PeraSpray™ Extension Kit APA/014



### **Properties**

Shield, Lance and Hook: Polypropylene

Gun Body & Lever and Connectors: Polypropylene

Tubing: PVC

Retractable coil: Nylon blend

'o' rings: EPDM

Flow rate: 2.37 – 2.74 litres/minute using water

Dimensions: 17 x 50 x 10 cm

Net weight: 0.44 Kg

#### Background

Milking clusters are a well-known source of cow to cow transmission of mastitis pathogens. For each infected cow milked, the risk of contamination is present for the next 6 to 8 cows, with the first two being at highest risk. An effective method of reducing the risk of mastitis transmission is by killing any pathogens present on the cluster before it is attached to the next cow.

Cluster spraying sanitises each cluster between each cow being milked, reducing cow to cow transmission of mastitis pathogens. This is a faster and more effective method than cluster dipping and enables fresh, clean solution to be delivered to the cluster every time.



## **Product Technical Data Sheet**

Peroxyacetic Acid (Peracetic Acid or PAA) is a particularly effective agent as well as being environmentally friendly and the only cleanser of choice for Organic milk producers. PAA breaks down into harmless components – carbon dioxide, water and oxygen, so there are no problems relating to milk contamination and there is no need to rinse the clusters.

Recommended for use with Peroxyacetic Acid (Peracetic Acid or PAA) at a final concentration of less than 3000ppm.

#### **Features**

- Extension kits enable expansion of the number of drop coils on the PeraSpray™ system.
- · Quicker and more effective than cluster dipping.
- Effective sanitisation of each cluster between every cow being milked with contact time of as little as 10 seconds.
- Fresh, clean solution is delivered to each cluster every time.
- Special applicators ensure that both the inside and outside surfaces of the cluster liner are sanitised.
- Contains the following parts which can be ordered separately as product codes:
  - APA/002 PeraSpray<sup>™</sup> Applicator.
  - APA/006 PeraSpray<sup>™</sup> Retractable Coil.
  - APA/008 PeraSpray<sup>™</sup> Nozzle 'O'-Rings for Spray Nozzle (pack of 10).
  - o APA/015 PeraSpray™ Solid Cone Nozzle.
  - AAF/017 PeraSpray™ Applicator Hanging Hook.
  - APA/020 PeraSpray<sup>™</sup> Nozzle and Shield Assembly.
  - o ATS/405-PA PeraSpray™ Control Valve Assembly.
  - o ATS/407 T-Connector with Nuts.
  - ATS/411 Cable Ties (pack of 10).
  - ATS/461-PA PeraSpray<sup>™</sup> Applicator Connector.

Manufactured in the UK
EU Tariff Code: 84349000

REACH compliance is not applicable.